CLEARANCES, LAYOUT WALL/KILN SPACING: 12" [30.5cm] SPACING BETWEEN SIDES OF KILN AND WALLS OR OTHER OBJECTS. 18" [45.7cm] IS RECOMMENDED. LEAVE AT LEAST 18" [45.7cm] BETWEEN TWO KILNS. **OTHER INFO: REFER TO INSTALLATION** INSTRUCTIONS AND CAUTIONS INSTRUCTIONS FOR OTHER REQUIREMENTS AND SAFETY INFORMATION. & INSTALLATION AMBIENT VENTILATION: SEE CHART BELOW FOR RATINGS. TO CALCULATE REFER TO WIRING DIAGRAM FOR ELECTRICAL REQUIREMENTS, SEE hotkilns.com/calculate-kiln-room-ventilation.

KILN VENTILATION: L&L VENT-SURE KILN VENT RECOMMENDED FOR SAFETY

AND LONGER ELEMENT LIFE. OPTIONAL CONTROL ALLOWS VENT TO BE HOOKUP INFORMATION. MAX LOAD WEIGHT: SEE hotkilns.com/load-weight WEIGHT OF KILN: 2245 LBS, 1018 KG TURNED ON AND OFF WITH CONTROL. VIEW SCALE - 1:15 12" RECOMMENDED LEAVE AT LEAST **BETWEEN HOT** 30" FREE SPACE **SURFACE AND** FROM A KILN **CONTROL PANEL** SURFACE FOR LEAVE 24" FREE **USER TO LOAD KILN SPACE IN FRONT** OF HOIST FOR **OPERATION AND** MAINTENANCE 86.6in [220cm] THIS MODEL IS DIRECT WIRED. THERE IS NO POWER CORD. LEAVE 24" FREE SPACE IN FRONT OF CONTROLLER FOR OPERATION AND MAINTENANCE 13.0in [33cm] 134.5in [341.7cm] BTUS/ KILOJOULES PER HOUR NEEDED TO BE VENTED WITH AMBIENT ROOM VENTILATION (THIS IS IN ADDITION TO KILN VENTING): AT TEMP C **KILOJOULES** AT TEMP F BTUS 1800F 43065 980C 45437 2000F 50705 1095C 53497 VENT TUBE OUTLET (OPTIONAL - PART OF VENT-SURE DOWNDRAFT VENT SYSTEM) 2232F 60351 1222C 63674 2350F 65580 1285C 69191 LIKINS SWEDESBORD NJ 08085 REV SHEET OF DRAWING NO. MADE FROM DRAWN BY DATE SCALE THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF PH: (856) 294-0077 FAX: (856) 294-0070 **0** 1/4 300-001-66 L&L KILN MFG INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF L&L KILN MFG INC. IS PROHIBITED. T3454-BL (3" BRICK) DAVINCI BELL-LIFT GENERAL DIMENSIONS NEW DSL 05/01/20 1:18 5





